Connections to Record the Value for Gain and Plot the Radiation Pattern for Horn Antenna

Horn Antenna INSTRUCTIONS To Record the Value for Gain and Plot the Radiation Pattern for Horn Antenna Klystron power supply 60 mVMore Components Check Connections Experiment setup Print Reset Components

Readings for Radiation Pattern of Horn Antenna

INPUT VOLTAGE $V_t = 330 \text{ mV}$

Angle (degrees)	$\mathbf{V_{r}}\left(\mathbf{mV}\right)$		$Gain (dB) = 20log_{10}(V_r/V_t)$	
	Clockwise	Anticlockwise	Clockwise	Anticlockwise
0	61	60	-14.66	-14.81
10	56	55	-15.41	-15.56
20	41	40	-18.11	-18.33
30	21	20	-23.93	-24.35
40	16	15	-26.29	-26.85
50	26	25	-22.07	-22.41
60	41	40	-18.11	-18.33
70	61	60	-14.66	-14.81
80	21	20	-23.93	-24.35
90	11	10	-29.54	-30.37

Graph

Radiation Pattern Of Horn Antenna

